



Uphoria 2 LED MR16 Lamp - Dimmer Compatibility List

Uphoria 2 LED MR16 lamps may operate on other dimmers and dimming systems not listed below.

The existence of a dimmer or transformer on this list is not a guarantee or warranty of the compatibility of the lamp / transformer / dimmer combination in all applications.

Actual performance of the lamps and dimmers may vary.



8W LED MR16 Codes: 1003920, 1003921

Dimmer Brand	Dimmer Model	HATCH RS12-15M-LED Transformer			HATCH VS12-75WD Transformer			HATCH RS12-30M-LED Transformer			B+L Technology FX95100 Transformer			Magnetic ARDE Light TW50 Transformer		
		Compatibility 1 lamp	Compatibility 3 lamps	Compatibility 5 lamps	Compatibility 1 lamp	Compatibility 3 lamps	Compatibility 5 lamps	Compatibility 1 lamp	Compatibility 3 lamps	Compatibility 5 lamps	Compatibility 1 lamp	Compatibility 3 lamps	Compatibility 5 lamps	Compatibility 1 lamp	Compatibility 3 lamps	Compatibility 5 lamps
Cooper	DLC038	Y	N	N	N	N	N	Y	Y	Y	Y	Y	Y	Y	N	Y
Lutron	SCL-153PR	Y	N	N	N	N	N	N	Y	Y	Y	Y	Y	Y	Y	Y
Lutron	MA CL-153-P	Y	Y	N	N	N	N	Y	Y	N	Y	Y	Y	Y	Y	Y
Leviton	6674	Y	N	N	N	N	N	N	Y	Y	Y	Y	Y	Y	Y	Y
Leviton	6673	Y	N	N	N	N	N	Y	Y	Y	Y	Y	N	N	N	N
Leviton	IPL06	Y	N	N	N	N	N	Y	Y	Y	Y	Y	Y	Y	Y	Y
Leviton	IF3005	N	N	N	N	N	N	N	N	N	Y	Y	Y	Y	Y	Y
Lutron	CTCL-153P	Y	N	N	N	N	N	Y	Y	Y	Y	Y	Y	Y	Y	Y
Lutron	MRF2-6ND	Y	N	N	N	N	N	Y	Y	N	Y	Y	Y	Y	Y	Y
Lutron	DV(W)JCL-153P	N	N	N	N	Y	Y	N	N	N	Y	Y	Y	Y	Y	N
Lutron	S-600P	N	N	N	N	N	N	N	N	N	Y	Y	Y	Y	Y	Y
Leviton	IPE04	Y	Y	Y	N	N	N	Y	Y	Y	Y	Y	Y	Y	Y	Y
Leviton	IPI06	Y	N	N	N	N	N	Y	N	N	Y	Y	Y	Y	N	N
Leviton	6615	Y	Y	Y	N	N	N	N	Y	Y	Y	Y	Y	N	N	N
Leviton	6613	Y	N	N	N	N	N	N	N	N	Y	Y	Y	Y	Y	Y

Dimmer Brand	Dimmer Model	Ligtech LET 60 Transformer			Ligtech LET 105 Transformer			Ligtech LVT-60 Transformer		
		Compatibility 1 lamp	Compatibility 3 lamps	Compatibility 5 lamps	Compatibility 1 lamp	Compatibility 3 lamps	Compatibility 5 lamps	Compatibility 1 lamp	Compatibility 3 lamps	Compatibility 5 lamps
Cooper	DLC038	N	N	N	N	N	N	N	N	N
Lutron	SCL-153PR	N	N	N	N	N	N	N	N	N
Lutron	MA CL-153-P	N	N	N	Y	Y	Y	N	N	N
Leviton	6674	N	N	N	N	N	Y	N	N	N
Leviton	6673	N	N	N	N	N	N	N	N	N
Leviton	IPL06	N	N	N	N	N	Y	N	N	N
Leviton	IF3005	N	N	N	N	N	N	N	N	N
Lutron	CTCL-153P	N	N	N	N	N	N	N	N	N
Lutron	MRF2-6ND	N	N	Y	N	N	N	N	N	N
Lutron	DV(W)JCL-153P	N	N	N	N	N	N	N	N	N
Lutron	S-600P	N	N	N	N	N	N	N	N	N
Leviton	IPE04	Y	N	N	N	N	N	N	N	N
Leviton	IPI06	N	N	N	N	N	N	N	N	N
Leviton	6615	Y	N	N	N	N	N	N	N	N
Leviton	6613	N	N	N	N	N	N	N	N	N

Y = Yes (Compatible)

N = No (Not Compatible)

Notes: Selector switch for 6674 is set to INC/LED. The slider on the DVCL is set in the middle.

USHIO is continually testing our LED products on various dimmers and dimming systems. We will continue to update this compatibility matrix as more results become available.

Specifications are subject to change without notice.