

NEWS RELEASE

USHIO AMERICA, INC.
5440 Cerritos Avenue, Cypress, CA 90630
Tel: 714.236.8600 • Fax: 714.229.3180
www.ushio.com

Contact:

Denny Huang - Sr. Marketing Coordinator
Tel: 714.229.3173, Email: press@ushio.com

FOR IMMEDIATE RELEASE

Ushio America Introduces Ubiquity™ LED T8 Direct Wire Lamps

Cypress, California (June 2016) — Ushio America, a leader in the specialty and general lighting marketplaces, introduces the Ubiquity™ LED T8 Direct Wire lamps which offer an energy-saving retrofit solution for F32T8 fluorescent lamps and they eliminate the need for external ballasts and LED drivers.

For OEM's and new installations all you need to do is simply connect the 120-277V line voltage directly to the tombstones. For retrofits, just bypass the existing ballast by cutting the wires and connect the 120-277V line voltage directly to the tombstones.

The Ubiquity LED T8 Direct Wire lamps have the form, fit and function of traditional T8 fluorescent lamps. With a rated lamp life of 50,000 hours, these 12.5W lamps are available in a 4000K color temperature and are made with a shatterproof glass tube. Glass provides very good thermal conductivity and transparency. The tube is frosted to prevent glare and allow the 240 degree beam angle (325 degree visible light area) to create a quality lighted environment.

USHIO is proud to stand behind these 50,000 hour rated life LED lamps with a 5-year warranty.

For more information on the Ubiquity LED T8 Direct Wire lamps, or any of the other lighting-edge technologies from Ushio America, visit www.ushio.com or call 800-838-7446.

About Ushio America, Inc.

Ushio America, Inc. is a leading manufacturer of specialty and general illumination lighting solutions based in Cypress, California. Established in 1967 as a subsidiary of Ushio Inc. (in Tokyo, Japan), the company now carries over 2,500 specialty and general lighting products. These Lighting-Edge Technologies™ are provided to a variety of industries, including semiconductor, printed circuit, PKG, general illumination, audio-visual, photographic, stage, studio and television, video projection, cinema, UV curing, germicidal, horticulture, graphic arts, flashlight, scientific, medical, dental, ophthalmic, infra-red heating, and many others. For further information, visit www.USHIO.com.

###