

Aladdin A-LITE

The Aladdin A-LITE is a high-end variable bi-color on-board LED light with an integrated and easy changable battery. The light quality of the Aladdin A-LITE is outstanding with CRI and TLCI ratings of over 95 for both tungsten and daylight. The integrated lithium-ion battery has a runtime of 1 hour and 20 minutes at full power and can be charged quickly via the included Micro USB-to-USB cable. This USB cable allows you to power and/or charge the A-LITE from any USB charger, laptop, camera or battery with a USB port.

The A-LITE is the slimmest and lightest on-board light on the market and the housing is made from air-craft-grade aluminum. The light comes with a standard 1/4-20" thread to mount to any on-board adapter. A removable hinged, plastic diffuser is included with the light to soften the light even further. The A-LITE produces a color temperature range from tungsten (2900°K) to daylight (6300°K) and every point in be-tween, and is completely dimmable from 100-5%.

FEATURES:

- Up to 97CRI / 95 TLCI
- Bi-Color 2900-6300K
- Dimmable 100-5%
- 2301ux/l m
- Micro USB Charging
- Lightweight & Micro Portable
- Flicker-free
- Available in 8W
- Removable Battery

AMS-08T/D



SPECIFICATIONS

Light Source	Super High CRI Power LEDs (8W)
Beam Angle	140°
Driver	Flicker-Free by CC Driver (efficiency>93%)
Switch	Switch: (ON/OFF)
Dimmer	Dimming: (100-5%)
Color Temperature	2900K–6300K
Battery	3.7V, 2.5A Li-ion Battery / Easy Changeable
Housing Material	Aluminium 6061 T6 (Aircraft grade)
Cooling	Passive Cooling
Dimension	156 x 80 x 11.5 mm
Weight	205 g
Power input	Micro USB 3.6V
Mounting	1/4 Screw

PHOTOMETRICS

	60cm/2ft	1m/3ft	2m/6ft	3m/9ft	CR
Daylight 6000K	840lux	230lux	60lux	32lux	92
Bi-Color 4200K	840lux	230lux	60lux	32lux	97
Tungsten 3000K	600lux	170lux	46lux	25lux	97

ACCESSORIES



AMS-02SHOE



AMS-08NBAT



AMS-08DF



AMS-FL40CLAMPPBH



AMS-02-MAG



AMS-02-POU2



AMS-02BALLSHOE



AMS-BA100