

Aladdin BASE-LITE

The BASE-LITE 100 and 200 are soft lights with a hard shell and offer many functions and possibilities. They are designed for portable and studio applications. The large face of the light provides soft lighting with clean reflections due to the evenly distributed diffuser. For a brighter and more powerful light the diffuser can be easily removed. The fixtures offer a high control of lighting, being dimmable from 100-0% in minute steps. Similarly, the color temperature can be adjusted to anywhere between 2900K and 6300K. Streamlined accessories are also available for the BASE-LITE 100 and 200, including barn doors and honeycomb grids.

The BASE-LITE 100 or 200 can be powered by a main power supply or batteries (V-Lock or Gold Mount), and you won't have any cables to deal with. The BASE-LITE also has built-in DMX module for full control in a studio setting. With its power, durability, and easy to use design, the new BASE-LITE 100 or 200 will revolutionize the way you work.

FEATURES:

- High CRI/TLCI: 98
- Variable Color 2900-6300K
- Stepless Dimming 100-0%
- DMX in/out
- Durable and Portable
- AC or DC Power (Gold Mount or V-Mount Option)
- Removable Diffusion for Max Output
- 100W or 200W kits



BASE-LITE 100



BASE-LITE 200

SPECIFICATIONS

Light Source	Super High CRI Power LEDs 100W & 200W
CRI	CRI 98 / TLCI 98
Color Temperature	2900K–6300K
Beam Angle	140°
Dimmer	Dimming: (1%–100%)
Cooling	Passive Cooling
Dimmer Input	12V to 30V
Power Unit	Automatic Voltage 90V–260V
Weight	BASE-LITE 100 = 2300g/5lbs; BASE-LITE 200 = 3800g/8lbs 6oz.
Dimension	BASE-LITE 100 = 430mm/17" width x 300mm/11.8" height BASE-LITE 200 = 500mm/19.65" width x 400mm/15.75" height

PHOTOMETRICS

Aladdin BASE-LITE 100

	60cm/2ft	1m/3ft	2m/6ft	3m/9ft	CRI
Daylight 6000K	6800lux	2700lux	840lux	450lux	99
Bi-Color 4200K	6800lux	2600lux	840lux	420lux	98
Tungsten 3000K	5500ux	2000lux	700lux	340lux	98

Aladdin BASE-LITE 200

	60cm/2ft	1m/3ft	2m/6ft	3m/9ft	CRI
Daylight 6000K	14000lux	5500lux	1700lux	840lux	99
Bi-Color 4200K	14000lux	4500lux	1600lux	800lux	98
Tungsten 3000K	11000ux	5500lux	1300lux	700lux	98

BASE-LITE 100



BASE-LITE 200

