

Aladdin BI-FLEX M7

The new BI-FLEX M7 (70W) and M3 (30W) is the cinematographer's dream come true. Both are small, lightweight and powerful LED lights, built with our new micro LEDs. The 70W BI-FLEX M7 is a 1'x1' (30x30cm) LED Panel and the BI-FLEX M3 is an 11.8 x 4.7 sized fixture. Their sleek, lightweight design makes them perfect for mobile lighting or studio applications. With the x-bender you will be able to mount the LED panel on a light stand with a 16mm (5/8) stud. The foldable and lightweight design of the x-bender ensures it will travel light and easy, with your travel gear. You can mount a diffuser to the x-bender for a softer light.

The included dimmer is universal and runs from main power supply or battery. You can use different sizes of panels with the same dimmer. The two control knobs on the dimmer give you full control over color temperature and intensity.

With the optional DMX module that can be attached to the dimmer, you are ready for a remote application. With this module it is easy to control the color and intensity of the LED light through your standard 512 DMX board.

FEATURES:

- High CRI: 98
 - Flexible Panel with NEW Micro-LED Technology
- Bi-Color 2900-5400K
- Dimmable 100%-0%
- Lightweight, Flexible and Foldable
- Available in 70W or 30W Kits
- AC or DC Power



SPECIFICATIONS

Light Source	Super High CRI Power LEDs 70W (M7) or 30W (M3)
CRI	CRI 98 / TLCI 98
Color Temperature	2900K-5400K
Beam Angle	140°
Dimmer	Dimming: (100-0%)
Cooling	Passive Cooling
Dimmer Input	12V to 30V
Power Unit	Automatic Voltage 100V to 240V



MFL 70BI



MFL 30BI