

# Aladdin EYE-LITE

There are three different versions of EYE-LITE available: Daylight, Tungsten or Bi-Color. The EYE-LITE (Bi-Color) is the newest to the family and has two integrated dimmers: one that adjusts color temperature between Tungsten (2900K) and Daylight (6300K) and one that controls light output from 100-5%. The unit has an integrated lithium-ion battery that provides a run-time of over two hours. The housing is made from aircraft aluminum and the quality of the light color is superior to nearly all other daylight LED lights on the market.

Each unit has a standard built-in 1/4" thread for universal mounting and a micro USB plug for charging. The EYE-LITE is ideal for many different applications. As the name implies, it's perfect for adding catch-lights in the eyes. Its power and small size allow it to be placed just about anywhere on set (inside furniture, shelves, lamps), as well as in tight spaces (cars, elevators, etc.).

## FEATURES:

- Up to 97CRI / 95 TLCI
- Bi-Color 2900-6300K
- Dimmable 100%-5%
- 2301ux/l m
- Micro USB Charging
- Slim, Sturdy, Lightweight & Portable
- Flicker-free by CC Driver (93% efficiency)
- Available in 2W
- Built-in Battery
- Long-life LEDs



EYE-LITE Bi-Color AMS-02T/D



EYE-LITE Tungsten AMS-02T



EYE-LITE Daylight AMS-02D

## SPECIFICATIONS

**CRI:** 97ra

**Color Temperature:** Daylight (6300K) / Tungsten (2900K)

**Beam Angle:** 140°

**Housing:** Aluminum 6061 (Aircraft grade)

**Cooling:** Air Convection

## ACCESSORIES



AMS-02 1/4TH



AMS-BA50



AMS-02-POU2



AMS-02-MAG



AMS-02CLIP



AMS-02FCLAMP



AMS-02SHOE



AMS-FL40CLAMPPBH



AMS-POUCH



AMS-02BALLSHOE