

# Aladdin FABRIC-LITE

The innovative new bi-color FABRIC-LITE, as the name implies, is completely flexible, foldable and offers great flexibility for transport. Mounting options for the FABRIC-LITE are virtually limitless, including all types of butterfly, overhead, wall and ceiling mounts, thanks to the integrated Velcro and grommets. The 3'x3' panel can be easily mounted on a Matthews frame or similar.

For stand-alone, use an optional Aladdin Frame and Diffuser (softbox with silver internal reflector) is available, converting the FABRIC-LITE into a 3'X3' soft light source that can be mounted on a light stand or attached to a lighting grid. Each 3x3-foot fabric panel can be used separately, or combined with others to create a light source as large as 12x12 feet (one Dimmer per Panel). The fixture offers high control over lighting. It is dimmable from 100-0% and the color temperature can be adjusted from 2900°K to 6300°K.

The Dimmer runs from main power supply or battery and has a built-in Lumen Radio module for DMX control. The included Dimmer features an integrated battery mount (Gold-Mount or V-Mount depending on the configuration ordered).

## FEATURES:

- High CRI/TLCI: 98
- Variable Color 2900-6300K
- Stepless Dimming 100-0%
- DMX In/Out
- Built-in Lumen Radio
- Lightweight, Flexible, Foldable
- 200W Power
- AC or DC Power (Gold Mount or V-Mount Option)
- Modular Kits available



*Aladdin*



\*Frame not included

### SPECIFICATIONS

<b>Light Source</b>	Super High CRI Power LEDs 200W
<b>CRI</b>	CRI 98 / TLCI 98
<b>Color Temperature</b>	2900K-6300K
<b>Beam Angle</b>	140°
<b>Dimmer</b>	Dimming: (100-0%)
<b>Cooling</b>	Passive Cooling
<b>Dimmer Input</b>	12V to 30V
<b>Power Unit</b>	Automatic Voltage 100V to 240V
<b>Battery Mount</b>	Integrated, V-Mount or Gold Mount

### PHOTOMETRICS

	<b>60cm/2ft</b>	<b>1m/3ft</b>	<b>2m/6ft</b>	<b>3m/9ft</b>	<b>CRI</b>
<b>Daylight 6300K</b>	8300lux	4200lux	1300lux	640lux	97
<b>Bi-Color 4200K</b>	9000lux	4500lux	1400lux	700lux	97
<b>Tungsten 2900K</b>	6800lux	3400lux	970lux	520lux	98

Contact your Zylight dealer at [www.zylight.com](http://www.zylight.com) | [zylightsales@ushio.com](mailto:zylightsales@ushio.com) | 800.838.7446

Specifications may be subject to change without prior notice. Refer to [www.zylight.com](http://www.zylight.com) for the most current product specifications.

FABRIC-LITE/1019

**zylight**

By **USHIO**