



# NANO SERIES (GOLD-MOUNT)



## Travel, Shoot, and Edit Anywhere with the FXLION NANO GOLD-MOUNT SERIES

From the innovative labs at FXLION comes the world's most compact Gold-Mount batteries for video and motion picture production. Lighten up your carrying load, charge anywhere, and power almost all of your gear. The NANO TWOA is a 98Wh lithium ion battery weighing only 1.2 lb. The NANO THREEA has a 150Wh capacity weighing only 1.7 lb and a working current of 10A.



Charge your NANO batteries anywhere with your mobile\* device charger via the Micro-USB and USB-C ports or through its D-Tap port or Gold-Mount charger. Use select ports to power your lights, camera, smart phone, USB-C laptops, and video accessories.

The NANO battery gives the power you need in the palm of your hand.

\* Some low voltage phone chargers may not be sufficient to charge the battery to full capacity. For USB-C charging, a 12-20V output charger at a maximum of 45W is recommended.



### APPLICATIONS:

- Cameras
- Monitors / Recorders
- Lights
- Laptops and Accessories



# SPECIFICATIONS

## FEATURES:

- LCD Display for Capacity and Voltage
- USB-C In/Out
- 2x D-Tap Ports
- Internal Cell Protection & Hard Plastic Casing
- PCB Design: Over-Heat, Over-Charge, Over-Discharge, and Over-Current Protection
- Compatible with Gold-Lock, D-Tap, and Laptop\* USB Charger
- Flight Friendly in Hand Luggage

\* Some low voltage phone chargers may not be sufficient to charge the battery to full capacity. For USB-C charging, a 12-20V output charger at a maximum of 45W is recommended.



## NANO TWOA SPECIFICATIONS - ITEM #1005415

<b>Mounting</b>	Gold-Mount
<b>Capacity</b>	6.8Ah, 98Wh
<b>Voltage</b>	14.8V
<b>Working Current</b>	10A (Max.)
<b>USB-A Output</b>	5V/2.4A, 9V/2A, 12V/1.5A
<b>USB-C Output / Input</b>	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/2.2A
<b>D-Tap Input / Output</b>	Yes (2X)
<b>Dimensions</b>	103mm (L) x 74mm (W) x 60mm (H) 4.1in (L) x 2.9in (W) x 2.4in (H)
<b>Weight</b>	530g / 1.2lb



## NANO THREEA SPECIFICATIONS - ITEM #1005416

<b>Mounting</b>	Gold-Mount
<b>Capacity</b>	10.2Ah, 150Wh
<b>Voltage</b>	14.8V
<b>Working Current</b>	10A (Max.)
<b>USB-A Output</b>	5V/2.4A, 9V/2A, 12V/1.5A
<b>USB-C Output / Input</b>	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/2.2A
<b>D-Tap Input / Output</b>	Yes (2X)
<b>Dimensions</b>	103mm (L) x 74mm (W) x 78.5mm (H) 4.1in (L) x 2.9in (W) x 3.1in (H)
<b>Weight</b>	765g / 1.7lb



**⚠ CALIFORNIA PROPOSITION 65 WARNING:** Lithium-ion Batteries and/or products that contain Lithium-ion Batteries can expose you to chemicals including cobalt lithium nickel oxide, and nickel, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).